



Steam a seam applied before going through tool. Be sure to remove paper after ironed in place.

Steam a Seam used was 1/4" wide

