



2 should be inside of 1. 4 #4s between sections of spring #3, and insert together, aligning tail of spring 3 in notches of stud 1 so that downward pressure is applied on thread by spring. Install 5, 6, 7, & 8. Get tension properly adjusted. Install dial 9 with about the indicator #4 up when adjusted for good straight stitch. Clamp with thumb nut 10. Insert #11, and secure with screw 12.